

ALLSYNC RECEIVER INSTALLATION MANUAL

PACKAGE CONTENTS:

- AllSync Receiver
- DC power adapter
- HDMI cable

NEEDED:

- USB-A touchback cable (touchscreen) or
USB-mouse (non-touch display)



CONNECT TO THE DISPLAY:


1. Connect the HDMI-cable between the AllSync Receiver device (by using the HDMI Out connector) and one of the HDMI inputs of your (touch) display.
2. Connect the USB-A touchback cable between the front of the AllSync Receiver and the touchscreen's touch out USB-connector (make sure you use the touch out that corresponds to the HDMI input you used on the touch display). In case of a non-touch display: Connect the USB-mouse to the AllSync Receiver.
3. Connect the power to the AllSync Receiver and switch the display to the HDMI channel for which you have connected the AllSync Receiver.
4. You should see the AllSync Receiver booting up and showing the home screen after about two minutes.

NOTE:

The AllSync Receiver may show a message about the 'License Manager'. This is caused by the device not being able to connect with the license server. This message will disappear as soon as the device is connected to a wired or wireless network with internet access.


CONNECT TO NETWORK:

1. If you want to connect to a wired Ethernet network:
Just plug the network cable into the device.
2. To connect to a Wi-Fi network, please execute the following steps:
 - a. Open the side menu on the left and choose 'Settings' (bottom button)
 - b. Choose 'Network & internet', then enable 'Wi-Fi' (switch on the right)
 - c. Choose your preferred Wi-Fi network and type in the password
 - d. Return to the home screen by opening the side menu and choosing the 'Home' (top button)



CHANGE THE ALLSYNC SHARING NAME

1. Open the side menu on the left and choose 'Settings' (bottom button).
2. Choose 'About device', then change 'Device name' to the desired sharing name.
3. The Receiver will give a popup to warn that the device will restart to change the device name. Press 'Restart'.




WIRELESS SHARING YOUR DEVICE (AND ALLSYNC CONFIGURATION)

The AllSync Receiver software and sharing work the same as the AllSync Receiver app on the i3CONNECT screens. Therefore, we refer you to i3CONNECT Docs for details on how to configure AllSync to your liking and share your screen wirelessly:

<https://docs.i3-connect.com/i3allsync>

FACTORY RESET DEVICE

1. Open the side menu on the left and choose 'Settings' (bottom button).
2. Choose 'System', then 'Reset'.
3. Choose 'Erase all data (factory reset)' and 'Erase all data' in the popup.
4. The device will erase all data and reboot.





i3CONNECT

www.i3-connect.com